

This file provided by

INFINITY
d a t a c o r p


Switch to Infinity Data Corp for your processing needs! Infinity offers great rates, excellent customer support and a wide range of payment processing solutions.

<http://www.infinitydata.com/>

Call Today!
866 746 8931

Omni 3600

Installation Guide



VERIX
OPERATING
ENVIRONMENT



SOFTPAY
E-PAYMENT
APPLICATION



VERIX
DEVELOPER
TOOLKIT
DEVELOPMENT
TOOLS



VERISHIELD
SECURITY
ARCHITECTURE



OMNI 37XX
HAND-OVER-COUNTER
MULTI-APPLICATION
APPLIANCES



OMNI 33XX
MULTI-APPLICATION
APPLIANCES



OMNI 3600
HAND-HELD
RADIO MODEM
APPLIANCES



VERICENTRE
APPLIANCE
MANAGEMENT
SUITE



Omni 3600 Installation Guide

© 2004 VeriFone, Inc.

All rights reserved. No part of the contents of this document may be reproduced or transmitted in any form without the written permission of VeriFone, Inc.

The information contained in this document is subject to change without notice. Although VeriFone has attempted to ensure the accuracy of the contents of this document, this document may include errors or omissions. The examples and sample programs are for illustration only and may not be suited for your purpose. You should verify the applicability of any example or sample program before placing the software into productive use. This document, including without limitation the examples and software programs, is supplied "As-Is."

VeriFone, the VeriFone logo, Omni, VeriCentre, Verix, and ZonTalk are registered trademarks of VeriFone. Other brand names or trademarks associated with VeriFone's products and services are trademarks of VeriFone, Inc.

All other brand names and trademarks appearing in this manual are the property of their respective holders.

Comments? Please e-mail all comments in this document to Tell_Us_More@VeriFone.com

WARNING



Do not dispose of the Li-ion smart battery in a fire. Li-ion batteries must be recycled or disposed of properly. Do not dispose of Li-ion batteries in municipal waste sites.



VeriFone, Inc.
2455 Augustine Drive
Santa Clara CA 95054-3002

www.verifone.com

Part Number 22060, Revision E



CONTENTS

CHAPTER 1 Introduction

Select a Location	7
Omni 3600 Terminal	7
Omni 3600 Base	7
Environment	7
Convenience	8
Safety Concerns	8

CHAPTER 2 Omni 3600 Terminal

Unpack the Shipping Carton	9
Terminal Features	10
Power Port	11
Smart Battery	11
Smart Battery Installation	12
Smart Battery Removal	13
Smart Battery Charging	13
Smart Battery Life	14
Turn On/Off the Omni 3600 Terminal	14
Paper Installation	14
Printer Test	16
Install/Replace MSAM Cards	16
Install/Replace SIM Card (GSM models)	18
Wireless Transactions	20
Smart Card Reader Transactions	20
Magnetic Card Reader Transactions	20
Antenna (Some Wireless Models)	21
Installation	21
Orientation	21
Replace the Antenna	22

CHAPTER 3 Omni 3600 Base

Unpack the Shipping Carton	23
Omni 3600 Base Features	24
Power Connection	26
Omni 3600 Terminal Docking	27
Spare Smart Battery Pack	27
Omni 3600 Base Communications Ports	28
Telephone Line Ports	28
Telephone Line Connections	29
Peripheral Devices	29
Optional Peripheral Device Port	29
Check Readers Supported	30
External Printers Supported	30

CHAPTER 4 Maintenance

Cleaning	31
Terminal and Base Contacts	31

	Card Readers	31
CHAPTER 5		
Troubleshooting	Troubleshooting Guidelines	33
	Terminal Does Not Start	33
	Terminal Does Not Turn Off	33
	Terminal Display Does Not Show Correct or Readable Information	33
	Smart Battery Will Not Charge	34
	Telephone Line Connection Does Not Work Properly	34
	Printer Does Not Work	34
	Serial Port Does Not Work	35
	Terminal Does Not Process Transactions	35
	Keypad Does Not Respond	36
CHAPTER 6		
VeriFone Service and Support	Return a Terminal, Base, or Smart Battery	37
CHAPTER 7		
Specifications	Power Requirements	41
	Environmental	41
	Omni 3600 Terminal Dimensions	41
	Weight	41
	Omni 3600 Base Dimensions	42
	Weight	42
CHAPTER 8		
Accessories and Documentation	How to Order	43
	Omni 3600 Terminal	43
	Download Cables and Adapters	43
	Cables for Optional Peripherals	43
	Base Station	43
	Telco Cable	43
	Smart Battery	43
	Power Pack	43
	Thermal Printer Paper	44
	Antenna	44
	VeriFone Cleaning Kit	44
	Omni 3600 Base	44
	Download Cables	44
	Cables for Optional Peripherals	44
	Telephone Line Cord	44
	Documentation	44
	Figure 1 Omni 3600 Terminal Shipping Carton Components	9
	Figure 2 Omni 3600 Terminal Features	10
	Figure 3 Connect Omni 3600 Terminal Power Pack	11
	Figure 4 Install the Smart Battery	13
	Figure 5 Smart Battery Charge Indicator LEDs and Test Button	14
	Figure 6 Open the Printer Cover	15
	Figure 7 Load Paper	15
	Figure 8 Close the Printer Cover	16
	Figure 9 Open the MSAM Access Door	17

Figure 10	MSAM Card Installation	17
Figure 11	MSAM Cardholder Lock Plate Detail	17
Figure 12	Insert MSAM Card into Cardholder	18
Figure 13	Remove SIM Door Screw	19
Figure 14	Slide Off SIM Card Access Door	19
Figure 15	Insert SIM Card into Cardholder	19
Figure 16	Using the Primary Smart Card Reader	20
Figure 17	Using the Magnetic Card Reader	20
Figure 18	Antenna Installation	21
Figure 19	Correct Antenna Position for Uplink	22
Figure 20	Omni 3600 Base Shipping Carton Contents	23
Figure 21	Omni 3600 Base Features: Top	24
Figure 22	Omni 3600 Base Features: Back (Telco models)	24
Figure 23	Power Pack Connection (Docked Terminal)	26
Figure 24	Spare Smart Battery Docking	27
Figure 25	Omni 3600 Base Connection Ports	28
Figure 26	Direct Connection	29
Figure 27	Pass-through Connection	29
Figure 28	Example Peripheral Connections	30
Figure 29	Omni 3600 Terminal Information Label Locations	38
Figure 30	Omni 3600 Base Information Label Locations	39
Figure 31	Smart Battery Information Label Locations	39



CHAPTER 1

Introduction

This guide describes how to set up and install an Omni 3600 terminal and Omni 3600 base. It also includes information on how to

- protect the terminal from adverse Environmental conditions,
- install and maintain the Smart Battery,
- establish communications connections through the Omni 3600 Base Communications Ports, and
- connect optional peripheral devices through the Omni 3600 base Peripheral Devices.

Select a Location

This section provides tips on using and protecting your Omni 3600 terminal, and location recommendations for the Omni 3600 base.

Omni 3600 Terminal

The Omni 3600 is a portable terminal for performing transactions remotely. Since it is a portable unit, location is not a factor however, follow the rules established in the Environment and Convenience sections.

Omni 3600 Base

A prime location for the Omni 3600 base is a counter or other flat surface that provides easy access to a power outlet and phone jack. Also, follow the rules established in the Environment and Convenience sections.

Environment

WARNING



Do not leave this terminal in an non-climate-controlled

vehicle. The Omni 3600 terminal is highly sensitive to temperature extremes. Subjecting the terminal to temperatures outside the stated operating range can void your warranty.



- Do not use the Omni 3600 terminal or Omni 3600 base where there is moisture or high humidity, chemicals or oils, or excessive heat or dust.
- Avoid locations near electrical appliances or other devices that emit excessive voltage fluctuations or electrical noise (for example, air conditioners, electric motors, neon signs, high-frequency or magnetic security devices, or computer equipment).
- Never place the terminal in direct sunlight.



CAUTION Do *not* use the Omni 3600 base outdoors. It is for indoor use only, and is not waterproof or dustproof. Damage to the unit from exposure to sun, rain, or dust may void your warranty.

- Keep the Omni 3600 terminal and Omni 3600 base away from anything that radiates heat, such as a stove or motor.



WARNING Do *not* use the Omni 3600 terminal or Omni 3600 base near water, including a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool. Avoid using these products during electrical storms.

- Ensure when transmitting over the radio modem that you are not near appliances that emit a lot of electrostatic “noise,” (for example, refrigerators or generators) and that you are in an area where you have a “clear” radio-frequency path.

Convenience **Omni 3600 Terminal**

Keep the Omni 3600 terminal with you to perform transactions. When plugging the Omni 3600 terminal into the power pack, ensure that the unit is placed close enough to a power outlet so that the power cable readily reaches the unit. For safety, do *not* string the power cable in a walkway or place across a walkway on the floor.

Omni 3600 Base

Locate the Omni 3600 base so that you can readily dock the Omni 3600 terminal on the cradle for recharging and downloading. Again, for safety, ensure that the power cable readily reaches the Omni 3600 base unit, so as not to trip or interfere in any way in a busy location.

Safety Concerns Use the following guidelines to ensure your safety and the safety of others:

- Do *not* string the power and phone cables in a walkway or place across a walkway on the floor.
- Do *not* use the Omni 3600 terminal or Omni 3600 base near water, including a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
- Avoid using the Omni 3600 terminal or Omni 3600 base during electrical storms.



WARNING Do *not* dispose of batteries in a fire. Li-ion batteries must be recycled or disposed of properly. Do not dispose of Li-ion batteries in municipal waste sites.



- Use only batteries and power packs approved by VeriFone.



CHAPTER 2

Omni 3600 Terminal

This section discusses the features of the Omni 3600 terminal, including

- providing power to the Omni 3600 terminal,
- charging the smart battery,
- installing paper,
- installing MSAM cards, and
- completing magnetic card and smart card transactions.

Unpack the Shipping Carton

Open the shipping carton and carefully inspect the contents for possible tampering or shipping damage (Figure 1).




Figure 1 Omni 3600 Terminal Shipping Carton Components

- 1 Remove the following items:
 - Omni 3600 terminal
 - Power pack and power cable (if present)
 - Roll of thermal printer paper
 - Battery pack
 - MOD10 adaptor (optional)
- 2 Remove all plastic wrap from the Omni 3600 terminal and components.
- 3 Remove the clear protective film from the display lens.

WARNING



Do *not* use a Omni 3600 terminal or Omni 3600 base that has been damaged or tampered with.

Terminal Features

Figure 2 illustrates the physical features of the Omni 3600 terminal.




Figure 2 Omni 3600 Terminal Features

Notice the following features of the Omni 3600 terminal shown in Figure 2:

- The display
- Four types of keys:
 - A 12-key, telephone-style keypad
 - Eight function keys: four function keys, labeled F1 to F4, right display; four unlabeled, *programmable* function (PF) keys above the keypad
 - Three keys (icons at left) under the keypad (left-to-right: CANCEL/OFF, BACKSPACE, ENTER/ON)
 - An ALPHA key center above the keypad (see ALPHA Key, page 33)
- The magnetic card swipe, above the display. The icon at left shows proper card orientation
- Smart card reader, in the front of the unit. The icon at left shows proper card orientation
- The internal thermal printer and door release
- The smart battery pack installed in back of unit (Figure 4)



- A SAM (security access module) access door, underneath the battery (Figure 9). The Omni 3600 terminal contains three micromodule-sized SAM (MSAM) cardholders to support multiple stored-value card programs or other merchant cards

The Omni 3600 terminal is equipped with a tamper-evident label (on a screw hole on the case bottom).

Power Port On the back of the Omni 3600 is one port—the *power* port. Use this port to connect the Omni 3600 to the power pack to recharge the battery through the unit

Connect Power Pack

To connect the Omni 3600 terminal to power:

- 1 Insert the round barrel connector (Figure 3) into the power port on the back of the terminal.
- 2 Insert the power cable into the power pack.
- 3 Plug the power pack into a wall outlet or surge protector.

NOTE



Install a power surge protector to protect against possible damage caused by lightning strikes and electrical surges.




Figure 3 Connect Omni 3600 Terminal Power Pack

WARNING



Do not plug the power pack into an outdoor outlet.

Smart Battery

The Omni 3600 wireless terminal uses an Li-ion *smart* battery (see *Accessories and Documentation* for ordering information). The internal logic of the smart battery prevents both overcharging and undercharging (a fault condition in which the battery level goes well below the minimum acceptable charge and the battery becomes unusable).



CAUTION Note that a new Li-ion battery's full performance is achieved only after two or three complete charge and discharge cycles.



On initial use, allow the Omni 3600 smart battery to charge 4 hours, then *fully discharge* during normal operation, to ensure reliable battery operation.

The following are features of the smart battery:

- Two Li-ion cells
- A fuel gauge module
 - monitors state of charge (voltage and current),
 - communicates with the terminal (charge parameters and alarms to indicate full discharge),
 - determines full charge capacity (on charge cycle and uninterrupted discharge cycle), and
 - automatically shuts down when cell voltage is extremely low.
- A safety circuit
 - prevents cell damage from overcharge/over-discharge,
 - activates when the battery is left in an unused terminal for extended periods, and
 - resets when battery voltage reaches a preset threshold during the charge cycle.

NOTE



Conserve battery power by turning the Omni 3600 terminal off when not in use. If the terminal is not to be used for several days, remove the battery from the terminal as it continues to discharge even when the terminal is turned off.

Refer to Spare Smart Battery Pack for smart battery instructions for the Omni 3600 terminal on the Omni 3600 base.

NOTE



The smart battery pack *must* be installed and holding a minimum of a 1% charge to operate the Omni 3600 terminal.

Smart Battery Installation

The smart battery installs in a slot on the back of the terminal, as shown in Figure 4. The locking tab clicks when the battery is in place. The slot is *keyed*, so that there is only one way to insert the battery.




Figure 4 Install the Smart Battery

Smart Battery Removal

To remove the smart battery, press the locking tab at the top of the battery and pull the smart battery from its slot.

Smart Battery Charging

On initial use, the smart battery must be fully charged and *fully discharged* through normal operation. After unpacking your Omni 3600 terminal, install the battery and connect the power pack to the unit for 4 hours. Disconnect the power pack and allow your Omni 3600 terminal to remain on until the smart battery completely discharges. Reconnect the power pack to the unit and allow the smart battery to recharge a maximum of 4 hours.

It is also recommended that the smart battery receive a periodic full discharge. To ensure a full discharge, use the unit until the battery is fully drained.

To determine the charge state of the battery, push the “test button” icon (shown in Figure 5) on the bottom of the battery. The bar LED status indicators on the battery each indicate 25% of the charge state. When the battery charge state reaches 10%, the ÷ LED (Figure 5) blinks, indicating a low-charge state. The battery charge state displays at the bottom of the first copyright screen when the terminal is turned on.

NOTE



Conserve battery power by turning the Omni 3600 terminal off when not in use. If the terminal is not to be used for several days, remove the battery from the terminal as it continues to discharge even when the terminal is turned off.

The smart battery has a safety circuit to protect the Li-ion cells from overcharging and over-discharging. If the battery is over-discharged, the safety circuit shuts down the battery and none of the indicator LEDs (see Figure 5) on the battery pack blink. The battery must then be recharged to restore operation.

NOTE



The Omni 3600 terminal automatically shuts off when the smart battery reaches the *critically low* charge state. If this occurs, the smart battery must recharge a minimum of 1/2 hour before it can power the terminal. **It make take several recharge attempts to reset the safety circuit** when charging a smart battery that has reached a critically low charge state.

If the Omni 3600 terminal is already running an application (for example, SoftPay), a battery status indicator may appear on the display.




Figure 5 Smart Battery Charge Indicator LEDs and Test Button

NOTE



It is recommended that you keep a spare, charged smart battery available.

Smart Battery Life

To ensure that you get the longest possible performance from the smart battery, it must be allowed to fully discharge periodically. The smart battery can be charged and discharged hundreds of times, but will eventually wear out. When operating times are noticeably shorter than usual, it is time to buy a new battery (see *Accessories and Documentation* for ordering information).

WARNING



Do not dispose of batteries in a fire. Li-ion batteries must be recycled or disposed of properly. Do not dispose of Li-ion batteries in municipal waste sites.



Turn On/Off the Omni 3600 Terminal



When the smart battery completes its initial charge, turn on the Omni 3600 terminal by pressing the green ENTER/ON key (icon at left) for approximately 3 sec. The display screen lights and displays the initial VeriFone copyright screen. If an application is loaded in the terminal, it starts after the initial VeriFone copyright screen and displays a unique (copyright) screen. If no application is loaded in the terminal, 0000000000000000 appears on screen after the initial VeriFone copyright screen.



Turn off the Omni 3600 terminal by pressing the red CANCEL/OFF key (icon at left) continuously until the cancel tone is heard (approximately 4 sec.). First a series of beeps is heard, then the cancel tone. The unit then shuts off.

Paper Installation

The internal thermal printer uses a roll of single-ply, thermal-sensitive paper 57 millimeters (2.25 inches) wide and 7.62 meters (25 feet) long. A pink *out-of-paper* indicator line appears on the edge of the paper approximately 18 inches before the end of the roll. After this line appears, there is enough paper remaining on the roll to conclude at least one transaction.

WARNING



Poor-quality paper may jam the printer. Order high-quality paper from VeriFone; refer to the ordering process listed in *Accessories and Documentation*.



Store thermal paper in a dry, dark, cool place. Handle thermal paper carefully; impact, friction, high temperatures, humidity, light, and oils affect the color and storage characteristics.

To install the paper roll in the internal thermal printer:

- 1 Lift paper roll cover tab to unlock the printer door (Figure 6).
- 2 Rotate the printer door up and back. Note that the door is hinged; it is not necessary to remove it from the unit.



Figure 6 **Open the Printer Cover**

- 3 Loosen the glued leading edge of the paper from the roll.
- 4 Hold the paper roll so paper feeds from the *bottom* (Figure 7) and pull approximately two inches of paper free of the roll.
- 5 Drop the paper roll into the printer tray, allowing the free paper to extend outside the printer door (Figure 7).




Figure 7 **Load Paper**

- 6 Close the cover by gently pressing directly on the paper roll cover tab until it clicks shut. Allow a small amount of paper to extend outside the cover, as shown in Figure 8.




Figure 8 Close the Printer Cover

NOTE



To prevent damage to the print roller on the paper roll cover, *a/ways* close the cover by gently pressing down on the paper roll cover tab.

Printer Test

To ensure the printer is operating correctly:

- 1 Turn on the terminal by pressing the green enter key (see Figure 2, page 10).
- 2 Enter system mode by pressing F2+F4 at the initial copyright screen, and entering the system mode password (see *Passwords*).
- 3 Toggle through the ðððððððððððð screens, using the down arrow key until you reach ðððððððððððððð.
- 4 Press F4 to enter the ððððððððððð screen.
- 5 Press F3, ðððð, to start the printer self-test.

The test printout, with printer information and repeating character strings, is approximately 38 cm (15 in.) long.

**Install/Replace
MSAM Cards**

When you first receive your Omni 3600 terminal, you may need to install a merchant smart card or one or more micromodule-sized security account manager (MSAM) cards, or you may need to replace old cards. Often, these small cards arrive on a larger, credit card-style plastic card, from which they must be removed. The following procedure describes MSAM card installation.

CAUTION



Observe standard precautions for handling electrostatically sensitive devices. Electrostatic discharges can damage this equipment. An anti-static wrist strap grounded to a metal surface is recommended.

- 1 Remove the battery (see *Smart Battery*)
- 2 Open the MSAM door located beneath the battery (Figure 9):
 - a Push down and back on the *raised arrow* on the door.
 - b Lift up on the raised arrow with the tip of your index finger.

- c Open the door until it is in the upright position, resting against the end of the terminal.




Figure 9 Open the MSAM Access Door

The three MSAM cardholders are now accessible. Each cardholder consists of a hinged tilt-up cover attached to a connector base (Figure 10).




Figure 10 MSAM Card Installation

- 3 Access the MSAM cardholders (reference Figure 10):
 - a Unlock the cardholder: Slide the lock plate to the unlocked position, in the OPEN direction (Figure 11).




Figure 11 MSAM Cardholder Lock Plate Detail

- b Open the cardholder by pivoting the cover on its hinge away from the connector base (Figure 12).




Figure 12 **Insert MSAM Card into Cardholder**

- 4 Remove any previously installed MSAM card by sliding the card from the cover.
- 5 Install an MSAM card by aligning the card and carefully sliding it within the guides on the cover until fully inserted.

NOTE



The cardholder has a set of contacts and a notch on one corner to ensure the MSAM card is positioned correctly when the cover is closed. The MSAM card has a notch on one corner to ensure it is correctly positioned in the cardholder. Before inserting the MSAM card, position it as shown in Figure 12.

- 6 Close the cover (Figure 12).
- 7 Lock each MSAM cardholder by sliding its locking plate towards the LOCK arrow until the plate stops (Figure 11).

CAUTION



To avoid damage to the MSAM cardholders, ensure each cardholder is locked before closing the MSAM door.

- 8 Close the MSAM door.
- 9 Replace the smart battery.

Install/Replace SIM Card (GSM models)

The SIM (Subscriber Identity Module) card is a smart card inserted in the Omni 3600 GSM terminal that contains your GSM radio account information. Use the following procedure to replace or install a SIM card.

- 1 Remove screw from SIM card access door on back of Omni 3600 terminal (Figure 13).




Figure 13 Remove SIM Door Screw

- 2 Remove the SIM card access door (Figure 14):




Figure 14 Slide Off SIM Card Access Door

- 3 Open the SIM card holder and slide the SIM card supplied by your provider into the cardholder (Figure 15).

NOTE



Do not lose the SIM card dust cover or retaining screw.



Figure 15 Insert SIM Card into Cardholder

NOTE



The SIM cardholder has a notch on one corner to ensure the SIM card is positioned correctly. The SIM card has a notch on one corner for easy orientation in the cardholder. Before inserting the SIM card, position it as shown in Figure 15, with the card's gold contacts facing down.

- 4 Replace the SIM card access door and screw.

Wireless Transactions

To conduct a wireless transaction:

- Ensure the terminal is in an optimal position for transmitting.
- Follow the on-screen instructions provided with your application.

Smart Card Reader Transactions

To conduct a smart card transaction:

- 1 Position the smart card with the contacts up and insert it into the smart card reader slot in a smooth, continuous motion until it seats firmly (Figure 16).

Leave the smart card in the card reader until the transaction is complete. Premature removal voids the transaction.




Figure 16 Using the Primary Smart Card Reader

- 2 Remove the card when the display indicates the transaction is complete.

Magnetic Card Reader Transactions

To conduct a credit/debit card transaction:

- 1 Position the card with the magnetic stripe facing down and towards the printer.
- 2 Swipe it through the reader from left-to-right, as shown in Figure 17.




Figure 17 Using the Magnetic Card Reader

Antenna (Some Wireless Models)

For some Omni 3600 terminals to establish a wireless connection, an external antenna is provided. This connection allows communication with your service provider to upload transaction data from the terminal and download system upgrades to the terminal. Radio service is activated by your service provider.

NOTE



Most Omni 3600 terminals have an internal antenna and this section can be ignored.

Only use the antenna designed for your unit. Failure to use the proper antenna results in the inability to establish a wireless connection.

CAUTION



Never hold the unit by the antenna; doing so may break the connection and void your warranty.

Data transfers can also be performed through the Omni 3600 base (see Omni 3600 Base Communications Ports).

This section only discusses Omni 3600 terminals with external antenna.

Installation

The Omni 3600 should arrive from manufacture with the antenna attached. If unattached, use the following procedure to install the antenna:

- 1 Locate the antenna port on the side of the Omni 3600 terminal.
- 2 Align the respective “notch” inside the antenna to the key in the terminal (Figure 18).
- 3 Push gently on the center of the base of the antenna until it locks in position.



Figure 18 **Antenna Installation**

Orientation

To establish good wireless communication (*uplink*), it is important that the antenna always be vertically aligned with respect to ground and sky (Figure 19). For example, if standing and holding the terminal horizontally, position the antenna at an approximately 90° angle to the unit (that is, pointing up from the printer). This should point the antenna directly at the sky.

If the unit is on a flat surface (for example, a table top) or docked in the Omni 3600 base, position the antenna so that it points directly at the sky. Soft detentes are felt and clicks heard when positioning the antenna. These detentes maintain antenna positions of 60°, 90°, and 180°.




Figure 19 **Correct Antenna Position for Uplink**

If an application (for example, SoftPay) is installed in your Omni 3600 unit, a signal strength indicator may appear on the display.

Replace the Antenna

If your Omni 3600 terminal has difficulties completing wireless transactions, you may have to replace the antenna. Use the following procedure to replace the antenna:

- 1** Remove the existing antenna from the Omni 3600 terminal:
 - a** Rotate the antenna to align with the base of the unit, pointing away from the back.
 - b** Grasp the base of the antenna, close to the body of the terminal.
 - c** Pull gently out until the antenna unsnaps from the antenna port.
- 2** Align the respective notch inside the new antenna to the key in the antenna port on the terminal (Figure 18).
- 3** Push gently on the center of the base of the newly installed antenna until it locks in position.



CHAPTER 3

Omni 3600 Base

This section discusses the features of the Omni 3600 base, including

- providing power to the Omni 3600 base,
- docking the Omni 3600 terminal,
- charging the smart battery in a docked terminal,
- charging a spare smart battery,
- establishing communications, and
- connecting peripheral devices.

The Omni 3600 base does not support PIN pad connections.

Unpack the Shipping Carton

Refer to Figure 20 and the following procedure while unpacking the Omni 3600 base shipping carton.




Figure 20 Omni 3600 Base Shipping Carton Contents

1 Remove the following items:

- Omni 3600 base
- Telco cable (optional)



NOTE The power pack and power cable, spare battery packs, and Telco cable are available separately. See *Accessories and Documentation* for ordering information.

2 Remove all plastic wrap from the Omni 3600 base and other components.

Omni 3600 Base Features

This section discusses the features of the Omni 3600 base.




Figure 21 Omni 3600 Base Features: Top



CAUTION Avoid touching the contacts in the raised area in the center of the Omni 3600 base. Finger oils tarnish contacts, causing bad connections. If the battery charge state or terminal power LEDs do not light when the terminal is docked, or there is a high occurrence of bad or incomplete data transfers, clean the contacts. See *Maintenance* for more information.




Figure 22 Omni 3600 Base Features: Back (Telco models)

The Omni 3600 base

- recharges the smart battery within a docked Omni 3600 terminal,
- charges a spare smart battery pack placed in the spare battery dock,
- establishes communications to a host through a 14.4 Kbps modem (Telco port), and
- connects to optional peripherals through the serial (RS-232) port (see *Peripheral Devices*).

The following are the physical features of the Omni 3600 base (Figure 21 and Figure 22):

- Three status LEDs (light emitting diodes) viewed left-to-right



- Terminal power LED:
 - Steady green indicates the battery in the terminal is fully charged or the terminal is docked, but has no battery.
 - Flashing amber indicates the battery in the terminal is receiving a *test charge* and is in the *precharge state*—the Omni 3600 base circuitry is determining the charge state of the battery in terminal.
 - Steady amber indicates the battery in the terminal is recharging.
















- Battery charge state LED:
 - Steady green indicates the spare battery docked in the Omni 3600 base is fully charged or is no longer charging.
 - Flashing amber indicates the spare battery is receiving a *test charge* and is in the *precharge state*—the Omni 3600 base circuitry is determining the charge state of the spare battery.
 - Steady amber indicates the battery in the spare battery dock is recharging.



- Omni 3600 base power LED:
 - Steady green indicates the Omni 3600 base is connected to the power adapter.
 - Not lit indicates the Omni 3600 base is not connected to the power pack, the power pack is not connected to the wall outlet, or the power is out.

Table 1 illustrates different LED states.

Table 1 Omni 3600 Base LED Status

Battery State	LED		
	 Terminal Power	 Spare Battery	 Omni 3600 Base Power
Fully charged battery in Omni 3600 terminal and spare battery in Omni 3600 base			
Pre-charge state			
Charging			
Omni 3600 base has power			

- Docking cradle: For Omni 3600 terminal (Figure 21) smart battery recharging and data transfers.

NOTE



The Omni 3600 terminal will not automatically turn off or *sleep* when docked; it must be turned off manually (see Turn On/Off the Omni 3600 Terminal).

- Spare battery docking station and optional spare battery: The recessed area in the top-rear of the Omni 3600 base is the dock to charge and store a smart battery. The spare battery LED does not light if no spare battery is present.



- Power port: The round port on back of Omni 3600 base (icon at left) connects the Omni 3600 base to the power pack.
- Communications ports: The ports on the back of the Omni 3600 base allow telephone or LAN line connectivity and peripheral device support.

Power Connection

The Omni 3600 base unit must be plugged in to a power outlet to

- recharge a smart battery in a docked terminal,
- charge spare smart batteries,
- communicate with peripheral devices, and
- establish Telco host connections.

WARNING



Do not plug the power pack into an outdoor outlet.






Figure 23 Power Pack Connection (Docked Terminal)

NOTE



It is recommended that the power pack be plugged into a power surge protector to protect against possible damage caused by lightning strikes and electrical surges.

To connect the Omni 3600 base to power (Figure 23):

-  1 Insert the round barrel connector into the power port (icon at left) on the far right of the Omni 3600 base.
- 2 Insert the power cable into the power pack.
-  3 Plug the power cable into a wall outlet or surge protector. When the Omni 3600 base is powered, the far-right LED (icon at left) lights steady green.

Omni 3600 Terminal Docking

Place the Omni 3600 terminal in the docking cradle (Figure 23) to recharge the terminal smart battery, establish communications connections for data transfers, and communicate with peripheral devices.

NOTE



The Omni 3600 terminal will not turn off or enter sleep mode while docked on the Omni 3600 base. This ensures that the unit is not placed into sleep mode during data transfers. **The unit must be turned off manually when docked on the Omni 3600 base.** See Turn On/Off the Omni 3600 Terminal.

Spare Smart Battery Pack

Spare smart battery packs for the Omni 3600 terminal can be ordered from VeriFone. See *Accessories and Documentation* for ordering information. To charge a smart battery in the Omni 3600 base, place the smart battery into the Omni 3600 base spare smart battery dock as shown in Figure 24. The smart battery dock is *keyed* so that the smart battery can only be inserted in one way.




Figure 24 Spare Smart Battery Docking


NOTE



Allow the spare battery to remain in the Omni 3600 base unit for a minimum of 2 hours, maximum of 4 hours to ensure the battery receives a full charge. Note that a new Li-ion battery's full performance is achieved only after two or three complete charge and discharge cycles.




Keep a spare smart battery charging in the Omni 3600 base battery dock to ensure that a fully charged battery is always available.

CAUTION  Conserve battery power by turning the Omni 3600 terminal off when not in use. If the terminal is not to be used for several days, remove the battery from the terminal as it continues to discharge even when the terminal is turned off.

If the Omni 3600 base unit is not plugged in, remove the smart battery from the dock to avoid the smart battery discharging in the Omni 3600 base unit.

On initial use, allow the Omni 3600 smart battery to charge a maximum of 4 hours and *fully discharge* during normal operation to ensure reliable battery operation. See Smart Battery for charge/discharge procedures.

WARNING  Do not dispose of batteries in a fire. Li-ion batteries must be recycled or disposed of properly. Do not dispose of Li-ion batteries in municipal waste sites.



Omni 3600 Base Communications Ports

The communications ports are located on the back of the Omni 3600 base (see Figure 25). When the Omni 3600 terminal is docked in the Omni 3600 base, a communication port in the terminal is opened, and data can transfer from the Omni 3600 terminal back and forth through the Omni 3600 base over the modem connection to and from your service provider or merchant contact.

NOTE



The Omni 3600 base must be plugged into power to establish communications connections.




Figure 25 Omni 3600 Base Connection Ports

WARNING



Do *not* remove the Omni 3600 terminal from the Omni 3600 base during data transfers. This terminates the connection and data loss may result.

Telephone Line Ports

There are two RJ11-type modular *phone* jacks (Figure 25) to connect the Omni 3600 base to a telephone line:



- The first port is identified by a telephone-shaped *Telset* icon shown at left. Use this port to connect a telephone to the terminal (*pass-through* connection)



- The second port is identified by the *Telco* icon shown at left. Use this port to directly connect the Omni 3600 series terminal to a telephone wall jack

Telephone Line Connections

To make a direct connection, connect a telephone cord from the Telco port on the Omni 3600 base directly to a telephone wall jack (Figure 26). Do not string the telephone cord across a walkway or place it so as to interfere in high-traffic areas. With a direct connection, the phone line is dedicated to the terminal.




Figure 26 Direct Connection

Pass-through connection — Run a telephone cord from the Telco port on the Omni 3600 base to the RJ11 jack on a standard telephone (Figure 27). Do not string the telephone cord across a walkway or place it so as to interfere in high-traffic areas. With a pass-through connection, the phone line is busy during downloads.




Figure 27 Pass-through Connection

Peripheral Devices

The Omni 3600 base supports a line of VeriFone peripheral devices designed to use with point-of-sale terminals. Use the RS-232 port on the back panel of the Omni 3600 base to connect these optional devices.

The following sections discuss the optional devices supported by the Omni 3600. Other optional devices may be supported. For more information, please contact your VeriFone distributor.

Optional Peripheral Device Port

Right of the RJ11 ports is a RJ45-type modular jack (serial port), labeled RS232:

- The RS232 serial port (icon shown at left) connects a VeriFone CR 600 check reader or other peripheral device to the Omni 3600 base

The Omni 3600 base does not support external PIN pad devices.

Check Readers Supported

The Omni 3600 base supports two VeriFone check readers: CR 600 and CR 1000*i*. Contact your VeriFone representative or visit the online store at www.verifone.com for information on these devices. Figure 28 provides an example of a peripheral connection.




Figure 28 Example Peripheral Connections

External Printers Supported

Although the Omni 3600 has an internal thermal printer (see Paper Installation), it may be convenient to print larger print runs (for example, daily or weekly reports) to an external printer. The Omni 3600 base supports three VeriFone external printers: P250, P350, and P900. Contact your VeriFone representative or visit the online store at www.verifone.com for information on these devices. External printer connections are through the same port as check readers (see Figure 28).



CHAPTER 4

Maintenance

This section discusses maintenance of the Omni 3600 terminal and Omni 3600 base.

Cleaning

For normal dirt, use a clean cloth slightly dampened with water and a drop or two mild soap. For stubborn stains, use alcohol or an alcohol-based cleaner.



Never use thinner, acetone, trichloroethylene, or ketone-based solvents — these chemicals can deteriorate plastic or rubber parts.

Do not spray cleaners or other solutions directly onto the keypad or display.



Terminal and Base Contacts

Gently swab the contacts with alcohol or contact cleaner to remove dirt. It is important that the exposed contacts in the docking cradle of the base stay clean and unbent.



Avoid touching the contacts in the raised area in the center of the base and the recessed area on the terminal. Finger oils tarnish contacts, causing bad connections. If the battery charge state or terminal power LEDs do not light when the terminal is docked or there is a high occurrence of bad or incomplete data transfers, clean the contacts.

Card Readers

The magnetic and smart card readers require no regular maintenance. For card reader service, contact your VeriFone distributor or service provider.



Do not attempt to clean the card readers. Doing so may void your warranty.



Troubleshooting

VeriFone follows stringent quality control standards in the manufacture of Omni 3600 terminals. Each unit that leaves the factory receives numerous tests to ensure quality and reliable operation. However, should you encounter a problem in operation, read this section for possible causes and solutions.

NOTE



The Omni 3600 terminal comes equipped with tamper-evident labels. Do not, under any circumstance, attempt to disassemble the terminal.

Troubleshooting Guidelines

The troubleshooting guidelines provided in the following section identify various problems and suggest appropriate corrective actions. If you have problems operating your Omni 3600 terminal, please read through these troubleshooting examples. If the problem persists or if it is not described below, contact your local VeriFone representative for assistance.

During normal, day-to-day operation of your Omni 3600 terminal, it is possible that minor malfunctions may occur. Here are some examples of possible problems and steps you can take to resolve them.

NOTE



Perform only those adjustments or repairs specified in this guide. For all other services, contact your local VeriFone distributor or service provider. Service conducted by parties other than authorized VeriFone representatives may void the product warranty.

Terminal Does Not Start

- Ensure that the smart battery charge state is not below the critically low level.
- Recharge or replace the smart battery.
- Ensure that you pressed the ENTER/ON key for approximately 3 seconds, until the unit lit up.

Terminal Does Not Turn Off

The Omni 3600 terminal will not shut off or go into sleep mode while docked in the Omni 3600 base. You must turn off a docked Omni 3600 terminal manually or remove the Omni 3600 terminal from the Omni 3600 base to allow it to enter sleep mode.

Terminal Display Does Not Show Correct or Readable Information

- Recharge or replace the battery.
- Dock the Omni 3600 terminal in a powered Omni 3600 base (if you have one) to see if this clears the problem, which points to a discharged battery.

If the problem persists, contact your local VeriFone representative for assistance.

Smart Battery Will Not Charge

The smart battery must initially receive a full charge and then full discharge to calibrate its full charge capacity. This operation is performed at manufacture; however, it is recommended that the battery receive a full charge/discharge once a year.

NOTE



Allow the Omni 3600 terminal to remain connected to the power pack for a minimum of 2 hours, maximum of 4 hours to ensure the battery receives a full charge.



Conserve battery power by turning the Omni 3600 terminal off when not in use. If the terminal is not to be used for several days, remove the battery from the terminal as it continues to discharge even when the terminal is turned off.

To discharge the smart battery, run the unit until the smart battery is fully drained.

NOTE



The Omni 3600 terminal automatically shuts off when the smart battery reaches the *critically low* charge state. If this occurs, the smart battery must recharge a minimum of 1/2 hour before it can power the terminal. **It make take several recharge attempts to reset the safety circuit** when charging a smart battery that has reached a critically low charge state.

Telephone Line Connection Does Not Work Properly

- Check the telephone line cord-to-base connections, and all telephone connections.
- Check the telephone line cord.
- If you are using a pass-through (Telset) connection, check that the telephone handset is seated properly in its cradle. Also, check the line using another telephone base unit. If the other telephone works, have the defective telephone repaired or replaced.
- If you are using a direct (Telco) connection, check the Telco cable by plugging it into a working telephone and listening for a dial tone. If this test does not work, replace the Telco cable.
- If it is determined that the telephone line is dead, contact your local telephone company to check the status of the line.

If the problem persists, contact your local VeriFone representative for assistance.

Printer Does Not Work

- Check battery status. The printer will not print if there is an insufficient charge remaining in the battery to complete the print operation.
- Check if the printer is out of paper and that the roll is properly installed. Open the paper roll cover and install a new roll of printer paper or ensure that the roll is feeding from the bottom.
- Verify that the printer roller and paper roll dust cover are properly installed.

If the problem persists, contact your local VeriFone representative for assistance.

Serial Port Does Not Work

- Check the power cable connection.
- Ensure the outlet has power.
- The serial port on the back panel of the Omni 3600 base is identified by the “RS232” icon. Check that the device connected to the serial port has power and is functioning properly. If possible, perform a self-test on the device in question.
- The cable connecting the optional device to the Omni 3600 base serial port may be defective. Try a different serial cable.

If the problem persists, contact your local VeriFone representative for assistance.

Terminal Does Not Process Transactions

There are several possible reasons why the terminal may not be processing transactions. Use the following steps to troubleshoot failures.

Step 1: Check the magnetic card reader

- Perform a test transaction using several different magnetic stripe cards to ensure the problem is not a defective card.
- Ensure that you are swiping cards properly. With the Omni 3600 card reader, the black, magnetic stripe on the card should face down, away from the keypad.
- Process a transaction manually using the keypad instead of the card reader. If the manual transaction works, the problem may be a defective card reader. Contact your VeriFone distributor or service provider.
- If the manual transaction does not work, proceed to Step 4.

Step 2: Check the smart card reader

- Perform a test transaction using several different smart cards to ensure the problem is not a defective card.
- Ensure that the card is inserted correctly. The chip on the card should be facing up and inward.
- Ensure the MSAM cards are properly inserted in the cardholders and the cardholders are properly secured (see *Install/Replace MSAM Cards*).
- If the manual transaction does not process, proceed to Step 4.

Step 3: Check the signal strength on-screen (SoftPay)

- Signal-strength indicator displays at least one bar to indicate connectivity to radio network.
- Check antenna connection and orientation.
- Ensure that the radio has been activated by your service provider.

Step 4: Check the telephone line

- Connect to a working telephone and check for a dial tone. If there is no dial tone, replace the Telco cable.

- If the problem appears to be with the telephone line, check with the party you are trying to call to see if their system is operational. If they are not experiencing difficulties with their line, contact the telephone company and have your line checked.
- If the telephone line works, contact your local VeriFone representative for assistance.

Keypad Does Not Respond

- Check the display panel. If it displays the wrong character or nothing at all when you press a key, follow the steps outlined in [Terminal Display Does Not Show Correct or Readable Information](#).
- If pressing a function key does not perform the expected action, refer to the user documentation for that application to ensure you are entering data correctly.

If the problem persists, contact your local VeriFone representative for assistance.



CHAPTER 6

VeriFone Service and Support

For Omni 3600 terminal or Omni 3600 base problems, contact your local VeriFone representative or service provider.

For Omni 3600 product service and repair information:

- United States: VeriFone Support Services, 1-800-837-4366, Monday–Friday, 8 A.M.–8 P.M. eastern time
- International: Contact your local VeriFone representative

For Omni 3600 supplies:

- VeriFone online store at www.store.verifone.com
- United States: VeriFone Support Services, 1-800-837-4366, Monday–Friday, 8 A.M.–8 P.M. eastern time
- International: Contact your local VeriFone representative

Return a Terminal, Base, or Smart Battery

Before returning an Omni 3600 terminal, Omni 3600 base, or smart battery to VeriFone, you must obtain a Merchandise Return Authorization (MRA) number. The following procedure describes how to return one or more Omni 3600 terminals, Omni 3600 bases, or smart batteries for repair or replacement (U.S. customers only):

NOTE



International customers, please contact your local VeriFone representative for assistance with your service, return, or replacement.

- 1 Gather the following information from the printed labels on *each* Omni 3600 terminal (Figure 29), Omni 3600 base (Figure 30), and smart battery (Figure 31) you are returning:
 - Product ID, including the model and part number. For example, “OMNI 3600” and “PTID XXXXXXXX” (if your terminal includes this number)
 - Serial number (S/N XXX-XXX-XXX)
- 2 Within the United States, call VeriFone toll-free at 1-800-837-4366.
- 3 Select the MRA option from the automated message. The MRA department is open Monday–Friday, 8 A.M.–8 P.M., eastern time.
- 4 Give the MRA representative the information gathered in Step 1.

If the list of serial numbers is long, you can fax the list, along with the information gathered in Step 1, to the MRA department. Include a telephone number where you can be reached and your fax number.

Please print clearly to the attention of the “VeriFone MRA Dept.” and send your fax to 727-953-4172 (U.S.). You will be issued an MRA number and the fax returned to you.

NOTE



One MRA number must be issued for each Omni 3600 terminal or Omni 3600 base you return to VeriFone, even if you are returning several of the same model.

- 5 Describe the problem and provide the shipping address to return the repaired or replacement unit.
- 6 Keep a record of the following items:
 - Assigned MRA number(s)
 - VeriFone serial number assigned to the Omni 3600 terminal, Omni 3600 base, or smart battery you are returning for service or repair (terminal serial numbers are located on the inside of the smart battery compartment; base serial numbers on the bottom of the unit; smart battery serial numbers on the side of the battery)
 - Shipping documentation, such as airbill numbers used to trace the shipment
 - Model(s) returned (model numbers are located on the VeriFone label on the bottom of the Omni 3600 terminal or Omni 3600 base)




Figure 29 **Omni 3600 Terminal Information Label Locations**




Figure 30 Omni 3600 Base Information Label Locations




Figure 31 Smart Battery Information Label Locations



Specifications

This section provides information on the power requirements, environmental conditions that the units can be subjected to, and unit dimensions.

Power Requirements

DC power (all Omni 3600 terminals and Omni 3600 bases): DC: 19VDC; 3.16A

DC power pack (all Omni 3600 terminals and Omni 3600 bases):

- Input: 100–240 V ~ (100–240VAC); 50–60 Hz; 1.5A
- Output: 19VDC; 3.16A

Barrel connector polarity (all Omni 3600 terminals and Omni 3600 bases):



Environmental

Omni 3600 terminal:

- Operating temperature: 0° to + 50° C (32° to 122° F)
- Storage temperature: – 20° to + 70° C (0° to 158° F)
- Relative humidity: 15% to 90%; no condensation

Omni 3600 base:

- Operating temperature: 0° to 55° C (32° to 131° F)
- Storage temperature: – 40° to + 70° C (–40° to 158° F)
- Relative humidity: 15% to 90%; no condensation

Omni 3600 Terminal Dimensions

- Height: 69 mm (2.72 inches)
- Width: 95 mm (3.74 inches)
- Length: 220 mm (8.64 inches)

Weight

- Terminal weight: 568 g (1.25 lb)
 - with battery installed: 681 g (1.5 lb)
 - with battery and paper roll installed: 710 g (1.56 lb)
- Shipping weight: 1264 g (2.78 lb): The shipping weight for the Omni 3600 terminal includes: shipping carton, one terminal, power pack and cable, one smart battery, paper roll, and one *Quick Installation Guide*.

Omni 3600 Base Dimensions

- Height: 88.9 mm (3.5 inches)
- Width: 95.25 mm (3.75 inches)
- Length: 241.3 mm (9.5 inches)

Weight

- Base station weight: 378 g (0.83 lb)
- Shipping weight: 498 g (1.098 lb): The shipping weight for the Omni 3600 base station includes: shipping carton, one base station, one Telco cable, and one *Quick Installation Guide*.



CHAPTER 8

Accessories and Documentation

This sections lists accessories and documentation available for the Omni 3600. When ordering, please refer to the part number in the left column.

How to Order

- VeriFone Online Store at www.store.verifone.com
- United States: VeriFone Customer Development Center, 1-800-837-4366, Monday–Friday, 8 A.M.–8 P.M., eastern time
- International: Contact your local VeriFone representative

Omni 3600 Terminal

This section presents accessory and part replacement ordering information for the Omni 3600 terminal. See VeriFone Service and Support for product service and repair information.

Download Cables and Adapters

05651-xx	MOD10-MOD10 (base station-to-base station)
26263-xx	02xxx MOD10-PC DB25F (base station-to-PC)
26264-xx	02xxx MOD10-PC DB9F (base station-to-PC)
22536-01	MOD10 adapter (terminal-to-terminal/PC/telephone)

Cables for Optional Peripherals

07041-xx	MOD10-MDIN9 (CR 600/CR 1000i check readers)
----------	---

Base Station

P096-201-00	Base station
-------------	--------------

Telco Cable

00124-17	2.1-m (7') telephone line cord, black color, with modular RJ11-type connectors
----------	--

Smart Battery

22044-02	7.4V battery pack
----------	-------------------

Power Pack

Contact your local VeriFone distributor to determine which power pack fits your needs.


22161-01	DC power pack (universal)
21973-01	Power cable (U.S.)

Thermal Printer Paper	CRM0043	Standard-grade thermal printer paper, 57-mm (2.25") width, 7.62-m (25') length; single roll
Antenna	Contact your VeriFone distributor to determine the exact antenna for your Omni 3600 terminal.	
	22066-XX	Replacement antenna.
VeriFone Cleaning Kit	02746-01	Cleaning kit
Omni 3600 Base	P096-201-00	Base, U.S., 14.4 Kbps modem
	P096-203-00	Base, generic 14.4 Kbps modem
Download Cables	05651-xx	MOD10-MOD10 (base-to-base)
	26263-xx	02xxx Mod 10-PC DB25F (base-to-PC)
	26264-xx	02xxx Mod 10-PC DB9F (base-to-PC)
Cables for Optional Peripherals	07041-xx	MOD10-Mini DIN9 (CR 600/CR 1000i check readers; P250/P355/P900 external printers)
Telephone Line Cord	00124-17	2.1-meter (7-foot) telephone line cord, black color, with modular RJ11-type connectors
Documentation	22377	<i>Omni 3600 Quick Installation Guide</i>
	22378	<i>Omni 3600 Base Station Quick Installation Guide</i>
	22060	<i>Omni 3600 Installation Guide</i>
	19733	<i>Verix Operating System Programmer's Manual</i>



VeriFone, Inc.
2455 Augustine Drive
Santa Clara CA 95054-3002
Tel: 800-VeriFone (837-4366)
www.verifone.com

VERIX
OPERATING
ENVIRONMENT



SOFTPAY
E-PAYMENT
APPLICATION



VERIX
DEVELOPER
TOOLKIT
DEVELOPMENT
TOOLS



VERISHIELD
SECURITY
ARCHITECTURE



OMNI 37XX
HAND-OVER-COUNTER
MULTI-APPLICATION
APPLIANCES



OMNI 33XX
MULTI-APPLICATION
APPLIANCES



OMNI 3600
HAND-HELD
RADIO MODEM
APPLIANCES



VERICENTRE
APPLIANCE
MANAGEMENT
SUITE



Omni 3600

Installation Guide

Figure 1	Omni 3600 Terminal Shipping Carton Components	9
Figure 2	Omni 3600 Terminal Features	10
Figure 3	Connect Omni 3600 Terminal Power Pack	11
Figure 4	Install the Smart Battery	13
Figure 5	Smart Battery Charge Indicator LEDs and Test Button	14
Figure 6	Open the Printer Cover	15
Figure 7	Load Paper	15
Figure 8	Close the Printer Cover	16
Figure 9	Open the MSAM Access Door	17
Figure 10	MSAM Card Installation	17
Figure 11	MSAM Cardholder Lock Plate Detail	17
Figure 12	Insert MSAM Card into Cardholder	18
Figure 13	Remove SIM Door Screw	19
Figure 14	Slide Off SIM Card Access Door	19
Figure 15	Insert SIM Card into Cardholder	19
Figure 16	Using the Primary Smart Card Reader	20
Figure 17	Using the Magnetic Card Reader	20
Figure 18	Antenna Installation	21
Figure 19	Correct Antenna Position for Uplink	22
Figure 20	Omni 3600 Base Shipping Carton Contents	23
Figure 21	Omni 3600 Base Features: Top	24
Figure 22	Omni 3600 Base Features: Back (Telco models)	24
Figure 23	Power Pack Connection (Docked Terminal)	26
Figure 24	Spare Smart Battery Docking	27
Figure 25	Omni 3600 Base Connection Ports	28
Figure 26	Direct Connection	29
Figure 27	Pass-through Connection	29
Figure 28	Example Peripheral Connections	30
Figure 29	Omni 3600 Terminal Information Label Locations	38
Figure 30	Omni 3600 Base Information Label Locations	39
Figure 31	Smart Battery Information Label Locations	39