This file provided by

INFINITY
d a t a   c o r p

Switch to Infinity Data Corp for your processing needs! Infinity offers great rates, excellent customer support and a wide range of payment processing solutions.

http://www.infinitydata.com/

Call Today!
866 746 8931

World Headquarters/ North America:

Hypercom Corporation
2851 W. Kathleen Road, Phoenix, Arizona 85053, USA • Tel: +1.602.504.5000 • Fax: +1.602.866.5380

HYC Latin America:

Hypercom Industria e Comercio LTDA
Centro Empresarial Atibaia
Rodovia Dom Pedro 1, KM 07, 5 Av.
Tegula, 888-Ponte Alta
Atibaia 12940-000, Brazil

Tel: +55.11.4417.7000
Fax: +55.11.4417.7060

HYC EMEA:

Hypercom EMEA
Unit 2, Woking Eight
Forsyth Road
Woking, GU21 5SB,
United Kingdom

Tel: +44.1483.718600
Fax: +44.1483.718601

HYC Asia:

Hypercom Asia
21/F Metro Centre II
21 Lam Hing Street
Kowloon Bay, Kowloon
Hong Kong

Tel: +85.2.2561.6800
Fax: +85.2.2561.5890

HYC Australia:

Hypercom Australia
Unit 1,
11 Orion Road
Lane Cove, NSW 2066
Australia

Tel: +612.9420.6444
Fax: +612.9420.6466

Supply Information:

If you are unable to purchase items such as paper through your bank or processor, contact Merchant Supplies at 800.522.8710.

Compliance:

This equipment is compliant with one or more of the following:
• FCC Part 15 (ICES-003)
• EN55022
• EN55024
• EN60950

940404-008, Rev. B   08/04

HYPERCOM®

www.hypercom.com ■ ■ ■ ■

ICE 5500 *Plus* to HFT 505/422

Hard Wired Installation Guide

www.hypercom.com

HYPERCOM®

ICE 5500 *Plus* & HFT 505/422

Required Equipment Check List

A1
ICE 5500 *Plus*

B1
Power Supply

C1
Telephone Cord

D1
Customer Supplied RJ45 Cable

E1
HFT 505/422

Connect the ICE 5500 *Plus* Terminal to the HFT 505/422

A1
PWR
Power RS232 Port

Electric Outlet

B1

A1
PIN LINE
PIN Port Line Port

Analog Phone Line

C1

D1

E1
RS422 Port